


Installation & Maintenance Manual

4-WAY CASSETTE TYPE



CHV-RS09SCC4W
CHV-RS12SCC4W
CHV-RS15SCC4W
CHV-RS19SCC4W
CHV-RS24SCC4W
CHV-RS30SCC4W
CHV-RS38SCC4W
CHV-RS48SCC4W
CHV-RS54SCC4W

IMPORTANT:

*READ AND UNDERSTAND
THIS MANUAL BEFORE
USING THIS HEAT-PUMP AIR
CONDITIONER.*

*KEEP THIS MANUAL FOR
FUTURE REFERENCE.*

T00907Q

Dear user:

Thank you for choosing and using our product. To better understand and use this product, please be sure to read and observe the following related issues before use.

IMPORTANT NOTICE

Signal words (DANGER, WARNING and CAUTION) are used to indicate hazard seriousness. Definitions of the hazard levels are provided below with respective signal words.

⚠ DANGER

: Immediate hazard that WILL result in severe personal injury or death.

⚠ WARNING

: Hazards or unsafe practices that COULD result in severe personal injury or death.

⚠ CAUTION

: Hazards or unsafe practices which COULD result in minor personal injury or product or damage.

NOTE

: Useful information for operation and/or maintenance.

- This manual should be considered as a permanent part of the air conditioning equipment. Please keep it properly.
- This manual describes and introduces this heat pump air conditioner in a unified manner, so it's applicable for your and other air conditioners.
- Our company pursues a policy of continuous improvement in design and performance of products. The right is therefore reserved to change specifications without notice.
- Our company shall not be held responsible for any occasional damage to the air conditioner that arises during its operation in specific environment. This air conditioner is designed for standard air conditioning only. Do not use it for other purposes such as drying cloth, refrigerating foods or for any other cooling or heating processes.
Please don't install the air conditioner in the following environments. Otherwise, fire, machine deformation or failure may arise.

* Places with spatter of oil (including machine oil).

* Places with sulfured gases or silicon (e.g. hot spring, etc.).

* Places with inflammable gases.

* Coastal areas with much salt or places exposed to strong acids or bases that may cause corrosion to machine.

- Do not have the air outlet directly faced towards animals or plants, since this may bring about an adverse effect thereon.
- The installation and service engineering have to comply with local standards, laws and regulations.
- As an "appliance inaccessible to the public", the installation height of indoor unit of the air conditioner shall be at least 8.2ft (2.5m).
- This air conditioner can only be installed by dealers or professionals. The installation by user may lead to water leakage, electric shock or fire.
- In case of any question, please consult the dealer or the service center designated by our company.
- For the operating temperature of the heat pump air conditioner, the range shall be set according to the outdoor unit manual.
- Refer to the instruction manual for complete machine (outdoor unit) for information about the product standards to which the indoor unit is subject.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- The models in this manual are partial units and shall only be connected to an appliance suitable for the same refrigerant.
- The models in this manual are partial units air conditioner, complying with partial unit requirements of the UL 60335-2-40, and must only be connected to the outdoors manufactured by Our company which have been confirmed as complying to UL 60335-2-40.


DANGER

- Please don't perform installation works such as refrigerant piping connection, drain pipe connection, and wiring connection. Violations may result in system leakage, electrical failure or fire. In the case of fire, please turn off the power immediately; please don't touch electrical parts with the hands, or electric shock may arise.
- Do not pour water into the indoor or outdoor unit. This machine is an electric product that may develop serious electric failure when exposed to water.
- Do not open the service cover of indoor or outdoor units without turning OFF the main power supply; otherwise, this may bring about serious safety accident.
- Do not touch or adjust safety devices inside the indoor or outdoor units. If they are touched or readjusted, serious accident may arise.
- Refrigerant R410A is non-flammable, non-toxic, and odorless, and may produce toxic gases when exposed to open flame. Since this refrigerant gas is heavier than air, it may result in lack of oxygen, thereby leading to breathing difficulties when the area near the ground is filled with this gas. If that's the case, please turn off the main switch immediately, cut off the power supply, and open the doors and windows for ventilation. Put out any open flame, and contact your service dealer. Performing leak detection and gas tightness test with oxygen, acetylene or other flammable and toxic gases may cause explosion, so nitrogen is recommended for this test.
- Refrigerant R32 is low burning velocity refrigerant, non-toxic, and odorless, and may produce toxic gases when exposed to open flame. Since this refrigerant gas is heavier than air, it may result in lack of oxygen, thereby leading to breathing difficulties when the area near the ground is filled with this gas. If that's the case, please turn off the main switch immediately, cut off the power supply, and open the doors and windows for ventilation. Put out any open flame, and contact your service dealer. Performing leak detection and gas tightness test with oxygen, acetylene or other flammable and toxic gases may cause explosion, so nitrogen is recommended for this test.
- The standards for safe refrigerant leakage in construction and system operation are determined based on local regulations or standards.
- Use ELB with high sensing speed (earth leakage breaker, with an actuation time of 0.1s or less). In the event of a fault, there is danger of an electric shock or a fire if it is not used.
- For installation, the refrigerant piping must be firmly connected before the operation of compressor. For repair, the refrigerant piping must be moved, handled and removed after the stop of compressor.
- Please don't short-circuit the protective device (e.g., the pressure switch, etc.) during operation, since this may cause fire or explosion.
- This unit is equipped with a refrigerant leak detector for safety. To be effective, the unit must be electrically powered at all times after installation, other than when servicing.

WARNING

- Do not use any sprays such as insecticide, lacquer, hair spray or other flammable gases within approximately 3.3ft. (1m) from the system. Ground Leakage Breaker GLB
- If the earth leakage breaker (ELB) is frequently activated, please stop the system and contact your local dealer or customer services.
- Make sure the ground wire is securely connected. The improper grounding of machine may lead to electrical failure. Please don't connect the ground wire to gas pipes, tap water pipes, lightning rods or phone ground wires.
- Make sure there are no flammable materials around during brazing operation. Please wear leather gloves to prevent frostbite when filling refrigerant.
- Prevent rats or other small animals damaging the wiring and electrical components. Bitten unprotected parts may cause a fire.
- Firmly fix the connection wires. The external force of terminal may result in looseness of terminal that may cause a fire.
- Make sure the air conditioner is installed with enough strength of fixation; otherwise, the air conditioner may fall or topple over, which may bring about machine damage or personal injury.
- Please follow the installation instructions and related regulations and standards for electrical construction; otherwise, electrical failure or fire may occur due to inadequate capacity or inconsistent specifications.
- Never fail to use specified wiring and select correct wiring, since failure to do so may cause electrical failure or fire.
- Please make sure the outdoor unit is not covered with snow or ice before use.
- The A-weighted emission sound pressure level at workstations, where this not exceeds 70 dB(A).
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater)
- Do not pierce or burn. Be aware that refrigerants may not contain an odour.

IMPORTANT NOTICE



Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

CHECKING PRODUCT RECEIVED

- Upon receipt of this product, check it for any shipping damage. Claims for damage, either apparent or concealed, should be filed immediately with the shipping company.
- Check the model number, electrical parameters (power supply, voltage, and frequency) and accessories to determine if they are correct. Please contact your local dealer in case of problem.

Our company shall not be held responsible for any consequence arising from the modification to equipment without our written consent.




TABLE OF CONTENTS

1. Safety Summary	1
2. Necessary Tools	8
3. Transportation & Handling	8
3.1 Transportation	8
3.2 Handling of Indoor Unit	8
4. Indoor Unit Installation	8
4.1 Factory-Supplied Accessories	8
4.2 Initial Check	9
4.3 Installation	9
5. Refrigeration Piping Work	11
5.1 Piping Materials	11
5.2 Piping Connection	12
6. Drain Pipe	13
7. Electrical Wiring	14
7.1 General Check	14
7.2 Electrical Wiring Connection	14
8. Test Run	16
9. Protection & Control Devices	16
10. Field Operation	17
10.1 Setting of DIP Switches	17
10.2 Setting of Fan Speed	17

1. Safety Summary

No part of this publication may be reproduced, copied, filed or transmitted in any shape or form without the permission of our company.

Within the policy of continuous improvement of its products, Our company reserves the right to make changes at any time without prior notification and without being compelled to introducing them into products previously sold. This document may therefore have been subject to amendments during the life of the product.

Our company makes every effort to offer correct, up-to-date documentation. Despite this, printing errors cannot be controlled by our company and are not its responsibility.

As a result, some of the images or data used to illustrate this document may not refer to specific models.

No claims will be accepted based on the data, illustrations and descriptions included in this manual.

No type of modification must be made to the equipment without prior, written authorization from the manufacturer.

During normal air conditioning system design work or unit installation, greater attention must be paid in certain situations requiring particular care in order to avoid injuries and damage to the unit, the installation or the building or property.

Situations that jeopardize the safety of those in the surrounding area or that put the unit itself at risk will be clearly indicated in this manual.

To indicate these situations, a series of special symbols will be used to clearly identify these situations.

Pay close attention to these symbols and to the messages following them, as your safety and that of others depend on it.

DANGER

- Our company is not able to foresee all the circumstances which may result in a potential danger.
- Do not pour water in the indoor or outdoor unit. These products are fitted with electric components.
- If water comes into contact with electric components, it will cause a serious electric shock.
- Do not handle or adjust the safety devices inside the indoor and outdoor units. The handling or adjustment of these devices may result in serious accident.
- Do not open the service cover or access panel of the indoor and outdoor units without disconnecting the main supply.
- In the event of fire, switch off the mains, put out the fire immediately and contact your service supplier.
- Check that the earth cable is correctly connected.
- The storage of equipment should be in accordance with the manufacturer's instructions.
- Do not install pipe work with diameters that are not specified for that model.
- Do not ground units to water pipes, gas pipes, telephone wires, or lightning rods as incomplete grounding can cause a severe shock hazard resulting in severe injury or death. Additionally, grounding to gas pipes could cause a gas leak and potential explosion causing severe injury or death.
- Do not install unit in an area where flammable materials are present due to risk of explosions that can cause serious

injury or death.

- Safely dispose all packing and transportation materials in accordance with federal/state/local laws or ordinances. Packing materials such as nails and other metal or wood parts, including plastic packing materials used for transportation may cause injuries or death by suffocation.
- Refrigerant gas is heavier than air and replaces oxygen. A massive leak can lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- If refrigerant gas leaks during installation, ventilate the area immediately. Refrigerant gas may produce toxic gas if it comes into contact with fire. Exposure to this gas could cause severe injury or death.

WARNING

- Only qualified personnel licensed or certified in their jurisdiction must carry out the installation work. Installation must be done in accordance with this installation manual. Improper installation may result in water leakage, electric shock, or fire.
- Pipe work and installation shall be in compliance with national codes (ASHRAE15 or IRC).
- Use only specified accessories and parts for installation work. Failure to use specified parts may result in water leakage, electric shock, fire, or the unit falling.
- Install the air conditioner or heat pump on a foundation strong enough that it can withstand the weight of the unit. A foundation of insufficient strength may result in the unit falling and causing injuries.
- Take into account strong winds, typhoons, or earthquakes when installing. Improper installation may result in the unit falling and causing accidents.
- Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel licensed or certified in their jurisdiction according to local, state, and national regulations. An insufficient power supply capacity or improper electrical construction may lead to electric shock or fire.
- Make sure that all wiring is secured, that specified wires are used, and that no external forces act on the terminal connections or wires. Improper connections or installation may result in fire.

- When wiring, position the wires so that the electrical wiring box cover can be securely fastened. Improper positioning of the electrical wiring box cover may result in electric shock, fire, or the terminals overheating.
- Before touching electrical parts, turn off the unit.
- The circuit must be protected with safety devices in accordance with local and national codes, i.e. a circuit breaker.
- Securely fasten the outdoor unit terminal cover (panel). If the terminal cover/panel is not installed properly, dust or water may enter the outdoor unit causing fire or electric shock.
- Do not use means to accelerate the defrosting process (if possible) or to clean, other than those recommended by the manufacturer.
- Assure that the maximum operating pressure is checked when connecting to Outdoor UNIT.
- This unit shall only be connected to an appliance suitable for the same refrigerant.
- System contains oversize protective earthing (grounding) terminal which shall be properly connected.
- When a fire occurs, cut off the power supply immediately.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Cleaning and user maintenance shall not be made by children without supervision.
- Wear adequate personal protective equipment (protective gloves, safety glasses,...) when installing, maintaining or servicing the system.
- The heat exchanger fins are sharp enough to cut. To avoid injury, wear gloves or cover the fins while working around them.
- Do not touch the refrigerant pipes during and immediately after operation as the refrigerant pipes may be hot or cold, depending on the condition of the refrigerant flowing through the refrigerant piping, compressor, and other refrigerant cycle parts. Your hands may suffer burns or frostbite if you touch the refrigerant pipes. To avoid injury, give the pipes time to return to normal temperature or, if you must touch them, be sure to wear proper gloves.
- Install drain piping to ensure proper drainage. Improper drain piping may result in water leakage and property damage.
- Insulate piping to prevent condensation.
- Be careful when transporting the product.
- Do not install the air conditioner or heat pump in the following locations:
 - Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen. Plastic parts may deteriorate and fall off or result in water leakage.
 - Where corrosive gas, such as sulfurous acid gas, is produced. Corroding copper pipes or soldered parts may result in refrigerant leakage.
 - Near machinery emitting electromagnetic waves. Electromagnetic waves may disturb the operation of the control system and cause the unit to malfunction.
 - Where flammable gas may leak, where there is carbon fiber, or ignitable dust suspension in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions can cause a fire.
- Take adequate measures to prevent the outdoor unit from being used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke, or fire. Instruct the user to keep the area around the unit clean.
- Servicing shall be performed only as recommended by the manufacturer and licensed or certified in their jurisdiction.

CAUTION

- Refrigerant leaks may hinder respiration as the gas displaces the air in the room. It is assumed that this heat pump air conditioner will be operated and serviced by English speaking people. If this is not the case, the customer should add safety, caution and operating signs in the native language.
- Fit the indoor unit, the outdoor unit, the remote controller and the cable at a minimum of 9.8ft(3m) away from sources of strong radiation from electromagnetic waves, such as medical equipment.
- Do not use sprays, such as insecticides, varnishes or enamels or any other inflammable gas within a meter of the system.
- If the circuit breaker or supply fuse of the unit comes on frequently, stop the system and contact the service supplier.
- Do not carry out maintenance or inspection work yourself. This work must be carried out by qualified service personnel with suitable tools and resources for the work.
- Do not place any foreign material (branches, sticks, etc.) in the air inlet or outlet of the unit. These units are fitted with high-speed fans and contact with any object is dangerous.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Means for disconnection from the supply mains, which have a contact separation in all poles that provide full disconnection under overvoltage category III conditions, must be incorporated in the fixed wiring in accordance with the wiring rules.
- The appliance shall be installed in accordance with national wiring regulations. The maximum working pressure is 4.30 MPa. This maximum working pressure shall be considered when connecting the indoor unit to outdoor unit.
- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.

- This air conditioner has been designed for standard air conditioning for human beings. For use in other applications, please contact your Our company dealer or service contractor.
- The air conditioning system should only be installed by qualified personnel, with the necessary resources, tools and equipment, who are familiar with the safety procedures required to successfully carry out the installation.
- PLEASE READ THE MANUAL BEFORE STARTING WORK ON THE INSTALLATION OF THE AIR CONDITIONING SYSTEM.
- Failure to observe the instructions for installation, use and operation described in this documentation may result in operating failure including potentially serious faults or even the destruction of the air conditioning system.
- It is assumed that the air conditioning system will be installed and maintained by responsible personnel trained for the purpose. If this is not the case, the customer should include all the safety, caution and operating signs in the native language of the personnel responsible.
- Do not install the unit in places where silicon gas is present. Any silicon gas deposited on the surface of the heat exchanger will repel water. As a result, the condensate water will splash out of the collection tray and into the electrical box. Water leaks or electrical faults may eventually be caused.
- Do not install the unit in a place where the current of expelled air directly affects animals or plants as they could be adversely affected.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

NOTES:

- The air in the room should be renewed and the room ventilated every 3 or 4 hours.
- The indoor unit should be positioned where the unit and interunit wires (outdoor to indoor) are at least 3.3ft (1m) away from any televisions or radios. (The unit may cause interference with the picture or sound.) Depending on the radio waves, a distance of 3.3ft (1m) may not be sufficient to eliminate the noise.
- Dismantling the unit, treatment of the refrigerant, oil and additional parts must be done in accordance with the relevant local, state, and national regulations.
- As maximum allowable pressure is 4.30MPa, minimum allowable pressure is 2.21MPa, the wall thickness of field-installed pipes should be selected in accordance with the relevant local, state, and national regulations.

Explanation of symbols displayed on the indoor unit or outdoor unit. (Only when using R32).

	WARNING	This symbol show that appliance uses a flammable refrigerant (A2L). If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire.
	CAUTION	This symbol shows that the Operation manual should be read carefully.
	CAUTION	This symbol shows that a service personnel should handle this equipment with reference to the Installation manual.
	CAUTION	This symbol shows that there is information included in the operation manual and/or Installation manual.

Precautions for R32

This air conditioner uses R32 flammable refrigerant. Air conditioner with R32 refrigerant, if not be treated carefully, may cause serious harm to the human body or surrounding things. Please read the following instructions carefully before installing, using and maintaining.

WARNING

- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn the refrigerant system to avoid the leakage.
- Be aware that refrigerants might not contain an odour.
- Do not charge R32 into system other than those designated for R32.
- Do not charge R32 system with oil other than those designated for R32.
- Do not use a reclaim cylinder other than an R32 reclaim cylinder.
- Be sure to only use refrigerant piping approved for use with R32 refrigerant. The use of unapproved piping may result in explosive rupture.
- The pipe-work shall be securely mounted and guarded from physical damage.
- The national gas regulations shall also be observed when field-installed refrigerant pipes are required.

- Field-made refrigerant joints indoors shall be tightness tested. The test method shall have a sensitivity of 0.01lbs (5 grams) per year of refrigerant or better under a pressure of at least 0,25 times the maximum allowable pressure. No leak shall be detected; Mechanical connections shall be accessible for maintenance purposes.
- The joints shall not be reused, unless after reflaring the pipe.
- Joints made in the installation between parts of the refrigerating system, with outdoor part charged, shall be made in accordance with the following.
 - A brazed, welded, or mechanical connection shall be made before opening the valves to permit refrigerant to flow between the refrigerating system parts. A vacuum valve shall be provided to evacuate the interconnecting pipe and/or any uncharged refrigerating system part.
 - Mechanical connectors used indoors shall comply with ISO 14903. When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be refabricated.
 - Refrigerant tubing shall be protected or enclosed to avoid damage.
- That after completion of field piping for split systems, the field pipework shall be pressure tested with an inert gas and then vacuum tested prior to refrigerant charging, according to the following requirements:
 - The minimum test pressure for the low side of the system shall be the low side design pressure and the minimum test pressure for the high side of the system shall be the high side design pressure, unless the high side of the system, cannot be isolated from the low side of the system in which case the entire system shall be pressure tested to the low side design pressure.
- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- The appliances are designed for use at altitudes less than 6561.7ft (2000m), may cause serious harm to the human body or surrounding things if used at altitudes 6561.7ft (2000m) and above.
- Keep any required ventilation openings clear of obstruction, don't block air inlet or air outlet, otherwise, the cooling or heating capacity will be weakened, even cause system stop operating or safety hazard.
- Maintenance or repair of air conditioner using R32 refrigerant must be carried out after security check to minimize risk of incidents.
- Ensure no following objects under the indoor unit:
 - Microwaves, ovens and other hot objects.
 - Computers and other high electrostatic appliances.
 - Sockets that plug frequently.
- Installation, maintenance, service, repairing, removing and disposal operations, shall only be performed by the qualified personnel or recommended by the manufacturer.
- Every working procedure that affects safety means shall only be carried out by competent persons. Examples for such working procedures are:
 - breaking into the refrigerating circuit;
 - opening of sealed components;
 - opening of ventilated enclosures.
- Precautions shall be taken to avoid excessive vibration or pulsation to refrigerating piping for the transport and installation.
- Protection devices, piping and fittings shall be protected as far as possible against adverse environmental effects, for example the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris.
- When installing or repairing the air conditioner and the connecting line is not long enough, the entire connecting line shall be replaced with the connecting line of the original specification; extension is not allowed.
- Refrigerating systems shall be so installed as to minimize the likelihood of hydraulic shock damaging the system.
- The appliance shall be installed and stored so as to prevent mechanical damage from occurring.
- Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the non-existence of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non sparking, adequately sealed or intrinsically safe.
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.
- No person carrying out work in relation to a refrigerating system which involves exposing any pipe work shall use any sources of ignition in such a manner that it can lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- Anti-static precautions is necessary for installing and maintenance, for example, wear pure cotton clothes and gloves.
- If R32 refrigerant leakage occurs during the installation, operators shall immediately detect the concentration in indoor environment until it reaches a safe level. If the leakage affects the performance of the machine, please immediately stop the operation, and the air conditioner must be vacuumed firstly and be returned to the maintenance station for processing.
- Where electrical components are being changed, they shall

be fit for the purpose and to the correct specification. At all times the maintenance and service guidelines of this manual shall be followed. If in doubt, consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using R32:

- The refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed.
- The ventilation machinery and inlets and outlets are operating adequately and are not obstructed; and shall keep away from heat source, inflammable or explosive conditions.
- Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected.
- Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.
- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised. Initial safety checks shall include:
 - that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking.
 - that no live electrical components and wiring are exposed while charging, recovering or purging the system.
 - that there is continuity of earth bonding.
- Sealed electrical components shall not be repaired.
- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.
- Air-tightness test shall be carried out as guaranteed. Charging oxygen, acetylene or other inflammable and toxic gases during leakage inspection and air-tightness test may lead to explosions. It is recommended to use nitrogen gas for this test.
- The following leak detection methods are deemed acceptable for all refrigerant systems.
 - Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity can be inadequate, or can need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (no more than 25 %) is confirmed.
 - The fluid used in leak detection is applicable to most refrigerants. But do not use chloride solvents to prevent the reaction between chlorine and refrigerants and the corrosion of copper pipeline.
 - If a leak is suspected, all naked flames shall be removed/extinguished.
 - If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated in a part of the system remote from the leak. Removal of refrigerant shall be according to this manual.
- When breaking into the refrigerant circuit to make repairs or for any other purpose conventional procedures shall be used. However, for flammable refrigerants it is important that best practice is followed since flammability is a consideration. The following procedure shall be adhered to:
 - safely remove refrigerant following local and national regulations;
 - evacuate;
 - purge the circuit with inert gas;
 - continuously flush with inert gas when using flame to open circuit;
 - open the circuit.
- The refrigerant charge shall be recovered into the correct recovery cylinders.
- Purging of the refrigerant circuit shall be achieved by breaking the vacuum in the system with inert gas and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. The system shall be vented down to atmospheric pressure to enable work to take place.
- Ensure that the outlet of the vacuum pump is not close to any potential ignition sources and that ventilation is available.
- In addition to conventional charging procedures, the following requirements shall be followed.
 - Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them.
 - Cylinders shall be kept in an appropriate position according to the instructions.
 - Ensure that the refrigerating system is earthed prior to charging the system with refrigerant.
 - Label the system when charging is complete (if not already labelled).
 - Extreme care shall be taken not to overfill the refrigerating system.
- Prior to recharging the system, it shall be pressure tested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.
- Before carrying out the decommissioning procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.

- Become familiar with the equipment and its operation.
- Isolate system electrically.
- Before attempting the procedure, ensure that:
 - (a) mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - (b) all personal protective equipment is available and being used correctly;
 - (c) the recovery process is supervised at all times by a competent person;
 - (d) recovery equipment and cylinders conform to the appropriate standards.
- Pump down refrigerant system, if possible.
- If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- Make sure that the cylinder is situated on the scales before recovery takes place.
- Start the recovery machine and operate in accordance with instructions.
- Do not overfill cylinders (no more than 80% volume liquid charge).
- Do not exceed the maximum working pressure of the cylinder, even temporarily.
- When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- Recovered refrigerant shall not be charged into another refrigerating system unless it has been cleaned and checked.
- Equipment shall be labelled stating that it has been decommissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.
- When removing refrigerant from a system, either for servicing or decommissioning, it is required to follow good practice so that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerant. Consult manufacturer if in doubt.
- In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition.
- The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process. Draining of oil from a system shall be carried out safely.
- Disposal of equipment shall follow the national regulations.
- The storage of the appliance should be in accordance with the applicable regulations or instructions, whichever is more stringent.
- The maximum number of pieces of equipment permitted to be stored together notes by each product package information and standard follows ISO 780-2015 or local regulation.
- After completing the installation work, check that the refrigerant gas does not leak throughout the system.
- When installing the unit in a small room, take measures to keep the refrigerant concentration from exceeding allowable safety limits. Excessive refrigerant leaks, in the event of an accident in a closed ambient space, can lead to oxygen deficiency.
- When installing or relocating the air conditioner, do not let any other substances besides R32, such as air, enter the refrigerant circuit. The presence of air or foreign matter in the refrigerant circuit causes an abnormal pressure rise, which may result in equipment damage and even injury.
- Refrigerant R32 in the system must be kept clean, dry, and tight.
 - Clean and Dry -- Foreign materials (including mineral oils such as SUNISO oil or moisture) should be prevented from getting into the system.
 - Tight -- R32 does not contain any chlorine, does not destroy the ozone layer, and does not reduce the earth's protection against harmful ultraviolet radiation. R32 can contribute to the greenhouse effect if it is released.
- Only use tools for R32, such as a gauge manifold, charge hose, gas leak detector, reverse flow checkvalve, refrigerant charge base, vacuum gauge, or refrigerant recovery equipment.
- If the conventional refrigerant and refrigerator oil are mixed in R32, the refrigerant may deteriorate.
- Appliance shall be installed, operated and stored in a room with a floor area larger than $A_{min} (m^2)$ [$A_{min} (m^2)$ - see table below].
- The installation of pipe-work shall be kept to a room with a floor area larger than $A_{min} (m^2)$ [$A_{min} (m^2)$ - see table below].
- The minimum room area is required based on UL 60335-2-40, and the indoor and outdoor units need to meet requirements of enhanced tightness refrigerating systems.

- If the refrigerant charge of R32 (m_c) ≥ 1.84 kg, the minimum room area is required based on UL 60335-2-40. This indoor units meet the requirements of enhanced tightness refrigerating systems, and the required minimum room area A_{min} to install the indoor unit with refrigerant charge m_c (kg) shall be in accordance with following: $A_{min} = (m_c / (2.5 \times LFL^{(5/4)} \times h_0))^2$, but not less than $A_{min} = (m_c / (0.5 \times LFL \times h_0))$.
- If the refrigerant charge of R32 (m_c) ≥ 15.96 kg, the indoor unit and outdoor unit need to meet the requirements of enhanced tightness refrigerating systems, and the refrigerant charge and room area should meet the requirements specified in the outdoor unit manual.

where

* A_{min} : minimum installation area of an Indoor unit for a given refrigerant charge m_c (kg) and considering the installation height h_0 (m²).

* h_0 : release height, the vertical distance from the floor to the bottom (the point of release) of the indoor unit when the unit is installed, in m, and it shall not be less than 2.0ft. (0.6m).

* m_c : total system refrigerant charge that could be released to the indoor area in case of undetected refrigerant leak, in kg.

* LFL: Lower Flammability Limit for R32, 0.307 kg/m³.

imperial

Minimum required room area for each refrigerant amount charged

4-Way Cassette (for single room)							
$h_0 = 7.2\text{ft. (2.2m)}^*$							
m_c (kg)	A_{min} (m ²)	m_c (kg)	A_{min} (m ²)	m_c (kg)	A_{min} (m ²)	m_c (kg)	A_{min} (m ²)
≤ 1.84	-	5.40	18.46	9.00	51.28	12.60	100.50
2.00	5.92	5.60	19.85	9.20	53.58	12.80	103.72
2.20	6.51	5.80	21.30	9.40	55.94	13.00	106.98
2.40	7.11	6.00	22.79	9.60	58.34	13.20	110.30
2.60	7.70	6.20	24.33	9.80	60.80	13.40	113.67
2.80	8.29	6.40	25.93	10.00	63.30	13.60	117.09
3.00	8.88	6.60	27.58	10.20	65.86	13.80	120.56
3.20	9.48	6.80	29.27	10.40	68.47	14.00	124.08
3.40	10.07	7.00	31.02	10.60	71.13	14.20	127.65
3.60	10.66	7.20	32.82	10.80	73.84	14.40	131.27
3.80	11.25	7.40	34.67	11.00	76.60	14.60	134.94
4.00	11.84	7.60	36.56	11.20	79.41	14.80	138.66
4.20	12.44	7.80	38.51	11.40	82.27	15.00	142.43
4.40	13.03	8.00	40.51	11.60	85.18	15.20	146.26
4.60	13.62	8.20	42.57	11.80	88.14	15.40	150.13
4.80	14.59	8.40	44.67	12.00	91.16	15.60	154.06
5.00	15.83	8.60	46.82	12.20	94.22	15.80	158.03
5.20	17.12	8.80	49.02	12.40	97.34	15.96	161.25

* The Minimum required room area in the above table is calculated by the $h_0 = 7.2\text{ft. (2.2m)}$. If the $h_0 < 7.2\text{ft. (2.2m)}$, the refrigerant charge and room area should meet the requirements specified in the outdoor unit manual.

NOTES:

SPRS-RS02

SPRSOB-RS15

- The Refrigerant Detector HOPT-ERD02 is assembled in the indoor unit.
- If the minimum room area and total system refrigerant charge do not comply with the above calculation formula, the optional part Refrigerant Shut-off Box HESE-2V15A2 need to be selected. Detailed installation instructions/periodic service/maintenance procedures/replace procedures can be found in the optional part manual and outdoor unit manual.
- The LEAK DETECTION SYSTEM includes the Refrigerant Detector HOPT-ERD02 (Assembled in the indoor unit) and the Refrigerant Shut-off Box HESE-2V15A2 (Optional parts). SPRSOB-RS15
- If the LEAK DETECTION SYSTEM is installed, unit must be powered according to the instructions except for service.
- For your safety, please contact distributor/service provider/manufacturer for regular inspection of gas samples and concentrations as specified in this clause in accordance with local laws and regulations.

SPRS-RS02

- The Refrigerant Detector HOPT-ERD02 has a lifespan of 10 years and a system response will be activated at the end of its service life to notify the end user to replace the detector. It is prohibited to use detectors whose service life has expired.
- During the use of the Refrigerant Detector HOPT-ERD02, do not use wet hands, alcohol or solvent cleaning, to avoid moisture.
- The Refrigerant Detector HOPT-ERD02 is prohibited for personal modification and maintenance. If any part is damaged, do not continue to use it. Please contact the distributors/service provider/manufacturer for repair or replacement.
- Under the start and self-checking state, the fan of connected indoor unit may continue to run for 90s, which is normal for detecting the air conditioning unit.

2. Necessary Tools

Necessary Tools and Instrument List for Installation

No.	Tool	No.	Tool	No.	Tool
1	Handsaw	8	Pipe Cutter	15	Gas Leak Detector
2	Phillips Screwdriver	9	Brazing Kit	16	Spirit level
3	Vacuum Pump	10	Hexagon	17	Clamper for Solderless Terminals
4	Refrigerant Gas Hose	11	Spanner	18	Hoist (for Indoor Unit)
5	Megohmmeter	12	Charging Cylinder	19	Ammeter
6	Copper Pipe Bender	13	Manifold Gauge	20	Voltage Meter
7	Manual Water Pump	14	Cutter for Wires		

NOTE

When in immediate contact with refrigerant, please use the installation tools and instruments dedicated to the new refrigerant.

3. Transportation & Handling

3.1 Transportation

Transport the product as close to the installation location as possible before unpacking.

⚠ CAUTION

Do not put any material on the product.

3.2 Handling of Indoor Unit

⚠ WARNING

Do not put any foreign material into the indoor unit and check to ensure that none exists in the indoor unit before the installation and test run. Otherwise, it may lead to a fire or failure, etc.

⚠ CAUTION

Be careful not to damage on insulation materials of unit surface when lifting.

4. Indoor Unit Installation

⚠ DANGER

Do not install the indoor unit in a flammable environment to avoid a fire or explosion.

Do not mix refrigerant R410A and refrigerant R32.

This unit is exclusive non electrical heater type indoor unit. It is prohibited to install a electrical heater in the field.

It's essential to remove the moisture, dust, other refrigerants or refrigerant oils from the refrigeration system. Hence, the failure to use specified materials and tools may result in explosion, personal injury, refrigerant leakage, electrical failure or fire.

⚠ WARNING

Do not install the indoor unit outdoors. If installed outdoors, an electric hazard or electric leakage will occur.

4.1 Factory-Supplied Accessories

- Check to ensure that the ceiling slab is strong enough. Otherwise, the indoor unit may fall down.
- Do not install the indoor unit outdoors. Otherwise, an electric hazard or electric leakage will occur.


It is recommended that indoor units be installed at least 8.2ft (2.5m) above the floor level.

Accessory	Quantity	Remark
Washer with Insulation Material (M10)	4	For unit installation
Washer (M10)	4	
Drain Hose	1	For Drain Hose Connection
Hose Clamp	1	
Pipe insulation	1	For refrigerant piping connection
Pipe insulation	1	
Cord clamp	2	For fixing remote control switch wiring, louver sensor and insulation of piping
Cord clamp	6	
Insulation (5Tx50x200)	1	For covering wiring connection
Insulation (5Tx270x270)	1	For covering drain connection

Tab. 4.1 Factory-Supplied Accessories

4.2 Initial Check


- Install the indoor unit in a space for easy operation and maintenance as shown in Fig. 4.1.
- Provide a service access door near the unit piping connection area on the ceiling.
- Check to ensure that the ceiling is strong enough to hang the indoor unit.
- Check if the ceiling surface is flat for the air panel installation.



Select the installation location as follows:


(A) Minimum Space

(B) Down Slope Pitch of Drain Pipe: 1/25~1/100



- The figure on the right shows the sensing area of motion detector when the motion detector in panel is in service.

Mounting height (h) of indoor unit	Approx. 8.9ft. (2.7m)	Approx. 9.8ft. (3.0m)	Approx. 13.8ft. (4.2m)
Sensing area ϕa of motion detector	Approx. 17.7ft. (5.4m)	Approx. 20.7ft. (6.3m)	Approx. 26.2ft. (8.0m)
Sensing area ϕb of motion detector	Approx. 9.8ft. (3.0m)	Approx. 11.2 (3.4m)	Approx. 14.1 (4.3m)




- The indoor unit must be installed at an appropriate location so that the indoor temperature can be evenly distributed.
- There should be no obstruction of air flow at the vent.
- Do not install the indoor unit in a machinery shop or kitchen where vapor from oil or its mist flows to the indoor unit. Once the oil deposits on the heat exchanger, it may impair the performance of indoor unit and cause damage to plastic parts therein.
- Pay attention to the following points when the indoor unit is installed in a hospital or other facilities where there are electronic waves from medical equipment, etc.
 - (A) Do not install the indoor unit where the electromagnetic wave is directly radiated to the electrical box, remote control cable or remote control.
 - (B) Install the indoor unit and components as far as practical or at least 9.8ft. (3m) from the electromagnetic wave radiator.
 - (C) Install the remote control switch in an iron box. Arrange the remote control cable in an iron tube. Ground the iron box and iron tube.
 - (D) Install a noise filter when the power supply emits harmful noises.
- To avoid any corrosive action to the heat exchangers, do not install the indoor unit in an acid or alkaline environment.

4.3 Installation

4.3.1 Opening of False Ceiling and Suspension Bolts

- (1) Select appropriate location and direction for installation of indoor unit, and determine its location. Pay careful attention to the space for the piping, wiring and maintenance.
- (2) Cut out the area for the indoor unit in the false ceiling and install suspension bolts, as shown in Fig. 4.4.



- (3) Ensure that the ceiling is horizontally level; otherwise, proper drainage flow would be impossible.
- (4) Strengthen the opening parts of the ceiling.

(5) Mount suspension bolts, as shown in the figure.





Fig. 4.5 Mounting the Suspension Bolts

4.3.2 Connection Points of Suspension Bolts and Pipes



Model	a	b	c
09	1/2 (12,7)	1/4 (6,35)	10-15/64 (260)
12	1/2 (12,7)	1/4 (6,35)	10-15/64 (260)
15	1/2 (12,7)	1/4 (6,35)	10-15/64 (260)
19	1/2 (12,7)	1/4 (6,35)	10-15/64 (260)
24	5/8 (15,88)	3/8 (9,53)	10-15/64 (260)
30	5/8 (15,88)	3/8 (9,53)	10-15/64 (260)
38	5/8 (15,88)	3/8 (9,53)	12-13/64 (310)
48	5/8 (15,88)	3/8 (9,53)	12-13/64 (310)
54	5/8 (15,88)	3/8 (9,53)	12-13/64 (310)

Fig. 4.6 Mounting Suspension Bracket

4.3.3 Mounting the Indoor Unit

Mount the indoor unit as shown in Fig. 4.6.

Mount field-supplied parts

Suspension bolt 4-M10 or W3/8

Nut 8-M10 or W3/8

Washer 8-M10 or W3/8

(1) Mount nuts and washers to the suspension bolts.




Fig. 4.7 Mounting Nuts and Washers

(2) Lift the indoor unit by hoist, and do not put any force on the water pan.

(3) Secure the indoor unit using the nuts and washers.




Fig. 4.8 Mounting the Indoor Unit

Note: If a false ceiling has already been installed, be sure to complete all piping and wiring works inside the ceiling before hooking-up the indoor unit.

4.3.4 Adjust the Distance between Indoor Unit and Ceiling

CAUTION

Please cover the machine with plastic cloth to keep it clean during installation.

- Check the level of water pan using a water level to avoid incorrect installation of drain discharge mechanism. The drain pipe side must be approximately 3/16in. (5mm) lower than other parts.
- Tighten the nuts of the suspension brackets after the adjustment is completed. Apply LOCK-TIGHT paint to the bolts and nuts in order to prevent them loosening. Otherwise, abnormal noise or sounds may occur and the indoor unit may fall down.

- (1) The pattern board for installation is in the packing carton. Please cut it off.






Fig. 4.9 Mounting Indoor Unit


- (2) Adjust the indoor unit to the correct position using the factory-supplied inspection ruler.



- (a) For suspended ceiling with panel installed.



- (b) For ceiling without panel.



Installation Details for Air Panel

- The details of installation work for air panel shall be according to the Installation Manual.
- Check to ensure the proper connection of connectors between the indoor unit and air panel.

5. Refrigeration Piping Work

DANGER

Use refrigerant R32 in the refrigerant cycle. Do not charge oxygen, acetylene or other flammable and poisonous gases into the refrigerant cycle when performing a leakage test or an air-tight test. These gases are extremely dangerous and can cause an explosion. It is recommended nitrogen be used for those tests.

5.1 Piping Materials

- (1) Prepare locally-supplied copper pipes.
- (2) Select clean copper pipes. Make sure there is no dust and moisture inside. Blow the inside of the pipes with nitrogen or dry air, to remove any dust or foreign matters before connecting pipes.
- (3) Select copper pipes based on table 5.2.

5.2 Piping Connection

- (1) The connection point and diameter of piping are shown in Figures 5.1 and table 5.2.





Fig. 5.1 Pipe Connection Points

Unit: in. (mm)

Capacity of indoor unit (kBtu/h)	Gas Pipe	Liquid Pipe
09~19	1/2 (Ø12,7) ※	1/4 (Ø6,35)
24~54	5/8 (Ø15,88) ※	3/8 (Ø9,53)

Table 5.2 Pipe Diameter

※ Since the nut cap connected at gas pipe is designed exclusively for R32 and R410A, the piping flaring connected for field installation is adjusted as compared with R22 and R407C. Please perform the processing operation based on the dimensions shown below: (See Fig. 5.3)



Unit: in. (mm)

Outside Diameter of Piping (a)		1/2 (Ø12,7)	5/8 (Ø15,88)
Outside Diameter of Flaring (D)	R22, R407C	41/64 (16,2)	49/64 (19,4)
	R32, R410A	21/32 (16,6)	25/32 (19,7)

Fig. 5.3 Flaring

- (2) As shown in follow picture, two spanners shall be used for tightening the nut. The detail tightening torque is in outdoor unit manual.




Fig. 5.4 Nut tightening torque

- (3) Insulate the refrigeration piping with field supplied insulating pipe upon completion of refrigerant pipe connection. See Fig. 5.5.





Fig. 5.5 Insulation on Pipes

CAUTION

- Cap the end of the pipe when the pipe is to penetrate a hole.
- Do not put pipes on the ground directly without a cap or vinyl tape arranged at the end of the pipe.

Do not put pipes on the ground directly



- (4) Discharging and Charging Refrigerant
Follow the Installation & Maintenance Manual for outdoor unit.


CAUTION

Excessive and inadequate refrigerant is a leading cause of system anomaly.

Please inject the right amount of refrigerant.

6. Drain Pipe

(1) The position of the drain pipe connection is shown next.



(2) Prepare a polyvinyl chloride pipe with a 1-1/4in. (32mm) outer diameter.

(3) Fasten the tubing to the drain hose with the adhesive agent and the factory-supplied clamp. The drain pipe must be performed with a down-slope pitch of 1/25 to 1/100.

Unit: in. (mm)





Fig. 6.1 Drain Pipe

* The total length a+b+c shall be $\leq 3.6\text{ft}$ (1.1m).

* In case of lifting the drain pipe at the outlet part, perform the drain piping work as shown in the figure above.

(4) Insulate the drain pipe after connecting the drain hose.



CAUTION

Where the relative humidity of air inlet or ambient air exceeds 80%, an auxiliary drain pan shall be fabricated at installation site and placed under the indoor unit, as shown in Fig. 6.2.





Fig. 6.2 Auxiliary Water Pan

CAUTION

- (1) The drain pipe installed shall slope down; otherwise, the condensate may flow back and leak into the room when the indoor unit is turned off.
- (2) The drain pipe shall not be connected with sewage pipe or other drain pipes.
- (3) Where the main drain is connected to other indoor units, each indoor unit must be higher than the main. Select drain pipes in ample size depending on the refrigerating capacity and quantity of indoor units.
- (4) Check if water flows without obstruction following the procedure shown below after the proper connection of wires and drain pipes.


- a. Turn on the power.
- b. Fill the drain pan with 68oz (2L) or 85oz (2.5L) of water.
- c. Check and ensure the water flows without obstruction and no leakage exists. Pour 68oz (2L) of water if no water flows out of pipe end.

- Inject water via access opening.



- Inject water via air outlet.

Insert the end of hose between heat exchanger and drain pan.



7. Electrical Wiring

⚠ WARNING

- Turn OFF the main power switches to the indoor unit and outdoor unit before electrical wiring or periodical check, and wait for at least ten minutes.
- Check to ensure the indoor and outdoor fans have stopped before electrical wiring or periodical check.
- Protect the wires, drain pipes, electrical parts, etc. from rats or other small animals. If not protected, rats may gnaw at unprotected parts, which may lead to a fire.
- Avoid the contact of wires with the refrigerant piping, sheet metal edges and electrical components in unit. Otherwise, the wires may get damaged or even cause a fire.
- Use ELB with high sensing speed (earth leakage breaker with an actuation time of 0.1s or less). In the event of a fault, there is danger of an electric shock or a fire if it is not used.
- The wires must be firmly secured. External force applied to terminals may cause a fire.
- It is forbidden to connect a plurality of power lines into one power terminal block. At the indoor unit side of air conditioner, power wiring can be extended through a power distribution box. Be sure to calculate the wiring capacity carefully, since excessively low wiring capacity may frequently cause fire.
- Do not start the system before all check points are thoroughly checked.
- The ELB (earth leakage breaker), FUSE and S (main switch) must be installed to the each power source of indoor unit group. If not, it may cause electrical shock or a fire.

⚠ CAUTION

- Wrap the wires with adhesive tape or other materials and plug the wiring connection hole with seal material to protect the product from any condensate water or insects.
- The electrical box entrance hole shall be designed with wire clamp that must be tightened to address tension requirements when penetrated by wires.
- Secure the remote controller wire in electrical box with wire tie.
- Tighten screws to the following torques.

Unit: ft·lbs (N·m)

- M4: 0,7~1 (1,0~1,3)
- M5: 1,5~1,8 (2,0~2,4)
- M6: 3~3,7 (4,0~5,0)
- M8: 6,6~8,1 (9,0~11,0)
- M10: 13,3~17,0 (18,0~23,0)

7.1 General Check


- (1) Make sure that the field-selected electrical components (main power switches, circuit breakers, wires, conduit connectors and wire terminals) comply with the National Electrical Code.
- (2) Check to ensure that the power supply voltage is within $\pm 10\%$ of the rated voltage. The system can't be started in the case of excessively low supply voltage.

- (3) Check the power capacity.
- (4) Ensure the ground wire is connected.
- (5) Check the capacity of the electrical wires. If the power source capacity is too low, the system cannot be started due to the voltage drop.

7.2 Electrical Wiring Connection


The electrical wiring connection for indoor unit is shown in Fig. 7.1.

- (1) Connect transmission wiring between the indoor unit and outdoor unit to the terminal board 1 and 2 in electrical box through the connection hole on electrical box.
- (2) Connect the power supply cable to the terminal board L1 and L2 in the electrical box, connect the earth wire to the earthing for power supply cable.
- (3) Connect the transmission wiring between the indoor unit and the wired controller to the terminal board A and B in electrical box.
- (4) Tightly clamp the wires with wire tie in the electrical box.
- (5) Upon completion of wiring connection, seal the wire interface with sealing material to keep condensate water and insects off.




Transmission wiring between indoor unit and outdoor unit




Wiring for wired controller



09~19 kBtu/h



24~54 kBtu/h



⚠ CAUTION

- Wiring is connected to the terminal board, be sure to use wire tie binding, wiring must be placed in the chute, to prevent the squeeze, a fire.

Fig. 7.1 Electrical Wiring Connection for Indoor Unit

Units			Power supply		Power supply cable size	Transmission cable size
Model (kBtu/h)	Hz	Volts	MCA (A)	MOP (A)		
09	60	208/230V	0,25	15	Wiring size and length must comply with local codes.	AWG18 (0,82mm ²)
12			0,38	15		
15			0,54	15		
19			0,63	15		
24			0,69	15		
30			0,70	15		
38			0,80	15		
48			1,50	15		
54			1,50	15		

MCA: Minimum Circuit Ampacity (A)

MOP: Maximum Overcurrent Protective Device (A)

Note:

- Field wiring shall be in conformity to local laws and regulations, and all wiring operations must be performed by qualified professionals.
- Refer to relevant standards for above-noted power cord size.

- (3) Power supply cable selection shall be compliant with requirements stated in UL 62 and C22.2 No.49, while the power supply cable shall be made from copper conductor.
- (4) Use the charts above to select appropriate sized breakers / fuses / overcurrent protection switches and wiring in accordance with local codes.
- (5) Ensure transmission wiring is a minimum of AWG18 (0.82mm²), 2-Conductor, Stranded Copper, Shielded Cable.
- (6) A switch that can ensure all-pole disconnection shall be installed between power supply and air conditioning unit in such a manner that the contact spacing shall not be less than 1/8 in. (3mm).
- (7) Once the power supply cable is damaged, the dealer or the professionals from designated maintenance department must be contacted in a timely manner for repair and replacement.
- (8) For the installation of power supply cable, the earth wire must be longer than the current-carrying conductor.
- (9) Select power supply cable size based on the value of the MCA.
- (10) Use shielded cables for transmission wiring and the shielding layer shall be grounded.
- (11) Select circuit breaker model based on the value of the MOP.
- (12) It is strictly forbidden to connect the power source wire from the terminal block to other units. In case of connecting to other units, distribution box shall be used for connection.

8. Test Run

Test run should be performed according to the Installation & Maintenance Manual.

WARNING

- Do not operate the system until all the check points are cleared.
- (A) Check to ensure the electrical resistance between terminal and ground is more than 1 MΩ. If this is not the case, do not operate the system until the electrical leakage is found and repaired.
- (B) Check to ensure the stop valves of outdoor unit are fully opened, and then start the system.
- (C) Check to ensure the switch on main power source has been ON for more than 4 hours to warm the compressor by heater.
- Pay attention to the following items while the system is running.
- (A) Do not touch any of the parts by hand at the discharge gas side, since the temperatures of compressor chamber and the pipes at the discharge side are higher than 194°F(90°C).
- (B) DO NOT PUSH THE BUTTON OF THE AC CONTACTOR. It will cause a serious accident.

9. Protection & Control Devices


Indoor Unit

Capacity of Indoor Unit (kBtu/h)		09~54
Capacity of Fuse on Indoor Unit Control Circuit	A	5
Freeze Protection Temperature	Cut-out	°F(°C) 32(0)
	Cut-in	°F(°C) 57(14)
Set Temperature Difference	Δ°F(Δ°C)	3,6(2)

10. Field Operation

10.1 Setting of DIP Switches

- (1) DIP switch must be set with power sources of the indoor and outdoor units in OFF state. Otherwise, the settings are invalid.
- (2) The DIP switches are located as shown in the figure below.



- (3) DIP switches are arranged on the PCB of indoor unit, and must be set based on the following instructions before test run. The system shall not be started before the completion of DIP switch setup.


- (a) Address of indoor units (DSW6): All indoor units must be numbered in sequence based on the diagram below. Outdoor units must be numbered from "0".

Setting Method	DSW6 (Setting 0~63)	Ex.) Set address No.16
	 Note: 8421 coding method	 No.5 is ON


- (b) Refrigeration system cycle Number (DSW5) is required to be set. All are set to OFF before shipment.

Setting Method 2	DSW5 (Setting 0~63)	Ex.) Set system No.16
	 Note: 8421 coding method	 No.5 is ON

- (c) Safety reset (DSW7)
 - * Factory settings



Once strong current is accidentally connected to Terminals 1 and 2 of TB2, the PCB fuse will be blown. In such a case, it's essential to correct the wiring and then to set switch number 1 to ON position.



Note:

Symbol "■" indicates the location of DIP switch. The position indicated in the diagram is in the factory-set state.

CAUTION

The power supply shall be turned off before the setup of DIP switch. Otherwise, the settings will be invalid.

10.2 Setting of Fan Speed

The air volume can be changed by performing external static pressure setup ("C5") on wired controller. Please refer to the wired controller Installation & Maintenance Manual.

Height of Ceiling		Setting of Wire Controller
09~24	27~54	
8.9ft. (2.7m)	10.5ft. (3.2m)	C5=00
8.9~9.8ft. (2.7~3.0m)	10.5~11.8ft. (3.2~3.6m)	C5=01
9.8~11.5ft. (3.0~3.5m)	11.8~13.8ft. (3.6~4.2m)	C5=02

Table 10.1 Comparison of 8421 Code and Decimal Number.

Decimal number	8421 Code					
	1	2	3	4	5	6
0	○	○	○	○	○	○
1	●	○	○	○	○	○
2	○	●	○	○	○	○
3	●	●	○	○	○	○
4	○	○	●	○	○	○
5	●	○	●	○	○	○
6	○	●	●	○	○	○
7	●	●	●	○	○	○
8	○	○	○	●	○	○
9	●	○	○	●	○	○
10	○	●	○	●	○	○
11	●	●	○	●	○	○
12	○	○	●	●	○	○
13	●	○	●	●	○	○
14	○	●	●	●	○	○
15	●	●	●	●	○	○
16	○	○	○	○	●	○
17	●	○	○	○	●	○
18	○	●	○	○	●	○
19	●	●	○	○	●	○
20	○	○	●	○	●	○
21	●	○	●	○	●	○
22	○	●	●	○	●	○
23	●	●	●	○	●	○
24	○	○	○	●	●	○
25	●	○	○	●	●	○
26	○	●	○	●	●	○
27	●	●	○	●	●	○
28	○	○	●	●	●	○
29	●	○	●	●	●	○
30	○	●	●	●	●	○
31	●	●	●	●	●	○
32	○	○	○	○	○	●
33	●	○	○	○	○	●
34	○	●	○	○	○	●
35	●	●	○	○	○	●
36	○	○	●	○	○	●

37	●	○	●	○	○	●
38	○	●	●	○	○	●
39	●	●	●	○	○	●
40	○	○	○	●	○	●
41	●	○	○	●	○	●
42	○	●	○	●	○	●
43	●	●	○	●	○	●
44	○	○	●	●	○	●
45	●	○	●	●	○	●
46	○	●	●	●	○	●
47	●	●	●	●	○	●
48	○	○	○	○	●	●
49	●	○	○	○	●	●
50	○	●	○	○	●	●
51	●	●	○	○	●	●
52	○	○	●	○	●	●
53	●	○	●	○	●	●
54	○	●	●	○	●	●
55	●	●	●	○	●	●
56	○	○	○	●	●	●
57	●	○	○	●	●	●
58	○	●	○	●	●	●
59	●	●	○	●	●	●
60	○	○	●	●	●	●
61	●	○	●	●	●	●
62	○	●	●	●	●	●
63	●	●	●	●	●	●

○: The current position is set to OFF

●: The current position is set to ON



1250426